

CHANDLER & PRICE CRAFTSMAN PRESS

with

**C. & P. Rice Automatic
Feeder**

10x15 and 12x18



Component Parts List

When ordering parts:—

Always give the serial number of the unit which is found stamped on the bed of the press in the upper left-hand corner.

Always give the size of press, part number, and the name and description of the part wanted.

Always state the definite mode of transportation, whether Air Mail—Express—Parcel Post—Freight.

When ordering by wire, use Code words listed in the left-hand column, specifying quantity of each part wanted. The Code word will indicate to us the number and name of the part.

Parts are shipped f.o.b. factory and any prices listed are subject to change without notice.

In practically all cases parts ordered will be shipped from the factory the same day the order is received.

Too much information is always better than not enough. A close observance of the above suggestions will eliminate the possibility of error and will expedite service.

COMPONENT PARTS LIST

Part Number	Part Shown on Plate No.	Code	Name and Description	Part Number	Part Shown on Plate No.	Code	Name and Description
BGR2	3	OBABU	Belt Guard Rear Support	CF19P	Not Shown	OBICA	Brayer Fountain Vibrating Roller Cam Pin
BGR2N	Not Shown	OBACE	Belt Guard Rear Support Screw Nut	CF19S	Not Shown	OBIDY	Brayer Fountain Vibrating Roller Cam Ball Screw
BGR2S	3	OBADO	Belt Guard Rear Support Screw	CF20A	Not Shown	OBIFE	Brayer Fountain Brayer Arm Shaft
BGR2W	Not Shown	OBABA	Belt Guard Rear Support Screw Washer	CF20EA	10	OBIGL	Brayer Fountain Spring
BGR4	Not Shown	OBAGR	Belt Guard Support Bracket	CF20EW	Not Shown	OBIIHA	Brayer Fountain Spring Washer
BGR5	2	OBABA	Belt Guard Brace Rod	CF20K	Not Shown	OBIIJA	Brayer Fountain Brayer Arm Key
BGR5LN	Not Shown	OBABJ	Belt Guard Brace Rod Nut	CF20P	Not Shown	OBIIKY	Brayer Fountain Brayer Arm Taper Pin
BGR5N	Not Shown	OBABS	Belt Guard Brace Rod Wing Nut	CF21AA	10	OBILD	Brayer Fountain Brayer Arm, Left
BGR5W	Not Shown	OBALM	Belt Guard Brace Rod Washer	CF21R	10	OBIMS	Brayer Fountain Spring Rod
BGR6A	Not Shown	OBAMI	Belt Guard Lower Support	CF21RC	Not Shown	OBINT	Brayer Fountain Spring Rod Cotter
BGR6N	Not Shown	OBANE	Belt Guard Lower Support Nut	CF21RS	10	OBIPU	Brayer Fountain Spring Rod Stud
BGR6SA	2	OBAPY	Belt Guard Lower Support Stud	CF21RSC	Not Shown	OBIQE	Brayer Fountain Spring Rod Stud Cotter
BGR6SN	Not Shown	OBART	Belt Guard Lower Support Stud Nut	CF21RSW	Not Shown	OBIRM	Brayer Fountain Spring Rod Stud Washer
BGR6W	Not Shown	OBASM	Belt Guard Lower Support Washer	CF21SS	Not Shown	OBIST	Brayer Fountain Brayer Arm Set Screw
BGR7	3	OBATU	Belt Guide	CF22AA	10	OBITH	Brayer Fountain Brayer Arm, Right
BGR7N	3	OBAVI	Belt Guide Nut	CF22R	10	OBIVE	Brayer Fountain Brayer Arm Safety Handle
BGR7W	3	OBABL	Belt Guide Nut Washer	CF221/2S	10	OBIWU	Brayer Fountain Swinging Arm Spring Rod Stud
BGR10	3	OBAXE	Belt Guide	CF23	10	OBIXL	Brayer Fountain Roll Large Gear
BL1	6	OBABO	Brake Lever	CF23P	Not Shown	OBIZO	Brayer Fountain Roll Large Gear Pin
BL1E	6	OBABM	Brake Lever Spring	CF24	10	OBJAW	Brayer Fountain Ratchet Lever
BL1P	6	OBABT	Brake Lever Pin	CF24PC	Not Shown	OBJEF	Brayer Fountain Ratchet Lever Stud Cotter
BL1PC	Not Shown	OBABIS	Brake Lever Cotter	CF25	Not Shown	OBJIG	Brayer Fountain Ratchet Pawl Spring Latch
BL2	6	OBABOF	Brake Lever Bracket	CF27A	Not Shown	OBJOB	Brayer Fountain Composition Roller Gear
BL2S	Not Shown	OBABUV	Brake Lever Bracket Screw	CF27C	Not Shown	OBJUS	Brayer Fountain Composition Roller Gear Cotter
BL2SN	Not Shown	OBACAT	Brake Lever Bracket Set Screw	CF28	Not Shown	OBKAM	Brayer Fountain Composition Roller Saddle, Left
BL2SS	6	OBCEC	Brake Lever Bracket Set Screw Washer	CF28C	Not Shown	OBKER	Brayer Fountain Composition Roller Saddle Cotter
BL2SW	Not Shown	OBCEID	Brake Lever Bracket Set Screw Lock Nut	CF28E	Not Shown	OBKIS	Brayer Fountain Composition Roller Saddle Spring
BL2SSN	Not Shown	OBCEOB	Brake Lever Bracket Set Screw Lock Nut	CF28S	Not Shown	OBKOF	Brayer Fountain Composition Roller Saddle Screw
BL3	3	OBCEUT	*Brake Shoe	CF281/2	Not Shown	OBKUP	Brayer Fountain Composition Roller Saddle, Right
BL3S	3	OBCEUT	Brake Shoe	CF29	Not Shown	OBLAS	Brayer Fountain Composition Roller Stock
BL3SN	Not Shown	OBCEUT	Brake Shoe	CF29 Cast	Not Shown	OBLEW	Brayer Fountain Composition Roller Stock Cast
BL4	Not Shown	OBCEUT	Brake Shoe	CF30	Not Shown	OBLIX	Brayer Fountain Bracket Rod, Short
BL5	6	OBCEUT	Brake Shoe	CF30N	Not Shown	OBLUG	Brayer Fountain Bracket Rod Nut
CF1A	Not Shown	OBCEUT	Brake Shoe	CF31	10	OBLUV	Brayer Fountain Bracket Rod, Long
CF1N	Not Shown	OBCEUT	Brake Shoe	CF34A	10	OBMAG	Brayer Fountain Index Plate
CF1R	Not Shown	OBCEUT	Brake Shoe	CF34N	10	OBMED	Brayer Fountain Index Plate Stud Wing Nut
CF11/2	Not Shown	OBCEUT	Brake Shoe	CF34S	Not Shown	OBMIN	Brayer Fountain Index Plate Stud
CF11/2LS	Not Shown	OBCEUT	Brake Shoe	CF34SW	Not Shown	OBMOK	Brayer Fountain Index Plate Stud Washer
CF11/2S	Not Shown	OBCEUT	Brake Shoe	CF35	10	OBMUL	Brayer Fountain Throw-Off Rod Stop Collar
CF2A	10	OBCEUT	Brake Shoe	CF35P	Not Shown	OBNAW	Brayer Fountain Throw-Off Rod Stop Collar Pin
CF21/2	10	OBCEUT	Brake Shoe	CF36A	10	OBNEG	Brayer Fountain Throw-Off Plate
CF21/2N	10	OBCEUT	Brake Shoe	CF36E	Not Shown	OBNIL	Brayer Fountain Throw-Off Plate Spring
CF3A	10	OBCEUT	Brake Shoe	CF36P	Not Shown	OBNOB	Brayer Fountain Throw-Off Plate Roller Pin
CF3S	Not Shown	OBCEUT	Brake Shoe	CF37	10	OBNUB	Brayer Fountain Throw-Off Plate Roller
CF4	10	OBCEUT	Brake Shoe	CF38	10	OBOSB	Brayer Fountain Ratchet Lever Roller
CF4S	Not Shown	OBCEUT	Brake Shoe	CF38S	Not Shown	OBOCI	Brayer Fountain Ratchet Lever Roller Stud
CF5	10	OBCEUT	Brake Shoe	CF43C	Not Shown	OBODY	Brayer Fountain Throw-Off Rod Cotter
CF5C	Not Shown	OBCEUT	Brake Shoe	CF43E	10	OBIFA	Brayer Fountain Throw-Off Rod Spring
CF5N	Not Shown	OBCEUT	Brake Shoe	CF45	10	OBIGI	Brayer Fountain Safety Stop Rod
CF5NP	Not Shown	OBCEUT	Brake Shoe	CF45E	Not Shown	OBIOHN	Brayer Fountain Safety Stop Rod Pin
CF5P	Not Shown	OBCEUT	Brake Shoe	CF45P	Not Shown	OBIOJE	Brayer Fountain Safety Stop Rod Guide Pin
CF5S	Not Shown	OBCEUT	Brake Shoe	CF46	10	OBOKA	Brayer Fountain Safety Stop Rod Handle
CF6	10	OBCEUT	Brake Shoe	CF46P	Not Shown	OBOLP	Brayer Fountain Safety Stop Rod Handle Pin
CF7	10	OBCEUT	Brake Shoe	CF49AA	10	OBOME	Brayer Fountain Roll Handwheel
CF7P	3	OBCEUT	Brake Shoe	CF49P	Not Shown	OBONS	Brayer Fountain Roll Handwheel Pin
CF7S	Not Shown	OBCEUT	Brake Shoe	CF55	10	OBOPB	Brayer Fountain Side Arm Washer
CF7SS	Not Shown	OBCEUT	Brake Shoe	CF55C	Not Shown	OBOPU	Brayer Fountain Side Arm Washer Cotter
CF7W	Not Shown	OBCEUT	Brake Shoe	CF55N	Not Shown	OBORN	Brayer Fountain Side Arm Washer Stud Nut
CF8	10	OBCEUT	Brake Shoe				
CF9	10	OBCEUT	Brake Shoe				
CF9L	Not Shown	OBCEUT	Brake Shoe				
CF9R	Not Shown	OBCEUT	Brake Shoe				
CF10	Not Shown	OBCEUT	Brake Shoe				
CF10S	Not Shown	OBCEUT	Brake Shoe				
CF13	10	OBCEUT	Brake Shoe				
CF15	Not Shown	OBCEUT	Brake Shoe				
CF16	10	OBCEUT	Brake Shoe				
CF18	Not Shown	OBCEUT	Brake Shoe				
CF19	Not Shown	OBCEUT	Brake Shoe				
CF19BB	Not Shown	OBCEUT	Brake Shoe				
CF19N	Not Shown	OBCEUT	Brake Shoe				



*Parts marked with an asterisk indicate special fitting and will be shipped with their mating part or parts
 IMPORTANT--Be sure to mention size of press for which parts are being ordered.



COMPONENT PARTS LIST—Continued

Part Number	Part Shown on Plate No.	Code	Name and Description	Part Number	Part Shown on Plate No.	Code	Name and Description
CF55P	Not Shown	OBOSK	Brayer Fountain Side Arm Washer Dowel	R12BSS	Not Shown	OCAHR	Crank Shaft Set Screw
CF55S	10	OBOTL	Brayer Fountain Side Arm Washer Stud	R12C	Not Shown	OCAJI	Crank Shaft Oil Cup
CF85T	10	OBOVE	Brayer Fountain Blade Adjusting Screw	R12T	5	OCAKO	Crank Shaft Oil Tube
CF89	10	OBOWT	Brayer Fountain Ratchet Wheel	R12TC	Not Shown	OCCALM	Crank Shaft Single Oil Tube Clip
CF89K	Not Shown	OBOXI	Brayer Fountain Ratchet Wheel Key	R12TCP	Not Shown	OCCALT	Crank Shaft Single Oil Tube Clip Rivet
CF90	10	OBOYS	Brayer Fountain Ratchet Pawl	R13	5	OCAMI	Pinion
CF90S	Not Shown	OBOZI	Brayer Fountain Ratchet Pawl Screw	R13K	5	OCANO	Pinion Key
CF90 $\frac{1}{2}$ S	Not Shown	OBPAN	Brayer Fountain Driver Stud	R14&33	5	OCAPU	*Large Gear Cam Wheel
CF90 $\frac{1}{2}$ SC	Not Shown	OBPES	Brayer Fountain Driver Stud Cotter	R14 $\frac{1}{2}$	Not Shown	OCARS	Large Gear Cam Wheel Steel Segment
CF90 $\frac{1}{2}$ SN	Not Shown	OBPIL	Brayer Fountain Driver Stud Nut	R14 $\frac{1}{2}$ S	Not Shown	OCCASM	Large Gear Cam Wheel Steel Segment Screw
CF90 $\frac{1}{2}$ SW	Not Shown	OBPOT	Brayer Fountain Driver Screw Washer	R15	4	OCCATI	*Rocker Lock Roller
CF92	10	OBPUK	Brayer Fountain Cover Knob	R15C	4	OCCAVA	Rocker Lock Roller Oil Cup
CF99	Not Shown	OBQAW	Brayer Fountain Name Plate	R15S	4	OCCAWK	Rocker Lock Roller Stud
CF99R	Not Shown	OBQER	Brayer Fountain Name Plate Rivet	R15SN	4	OCCAXY	Rocker Lock Roller Nut
CFR24P	10	OBQIK	Brayer Fountain Ratchet Lever Stud	R16	6	OCCAYN	Small Head and Lock Cam
CFR26	10	OBQON	Brayer Fountain Ratchet Rod	R17	3	OCCAZE	Roller Arm
CFR36S	10	OBQUE	Brayer Fountain Throw-Off Plate Stud	R17N	Not Shown	OCCBAD	Roller Arm Stud Nut
CFR43	10	OBRAY	Brayer Fountain Throw-Off Rod	R17S	6	OCCBEG	Roller Arm Stud
CFR90 $\frac{1}{2}$	Not Shown	OBRED	Brayer Fountain Driver	R17W	3	OCCBIN	Roller Arm Washer
CFR90 $\frac{1}{2}$ S	Not Shown	OBRIQ	Brayer Fountain Driver Screw	R17WS	3	OCCBOR	Roller Arm Washer Screw
ER1A	3	OBROT	Motor Bracket	R18	5	OCCBUM	Gripper Cam Roller
ER1S	Not Shown	OBRUZ	Motor Bracket Screw	R18SA	6	OCCCAL	Gripper Cam Roller Stud
ER1SS	3	OBSAK	Motor Bracket Set Screw (Short)	R18SN	Not Shown	OCCCEB	Gripper Cam Roller Stud Nut
ER1SSN	Not Shown	OBSEK	Motor Bracket Set Screw (Long)	R20	10	OCCCIK	Hand Feed Table Bracket
ER1 $\frac{1}{2}$ SS	3	OBSSN	Motor Bracket Set Screw (Long)	R21	6	OCCCOF	*Roller Frame, Left
ER3AA	3	OBSSC	Motor Bracket Rail (Short)	R21S	6	OCCCUR	Roller Frame Arm Stud
ER3N	3	OBSTU	Motor Bracket Rail Nut	R22	3	OCCDAM	Roller Frame, Right
ER3S	3	OBSTP	Motor Bracket Rail Screw	R22 $\frac{1}{2}$	3	OCCDET	Disc Lever Cam
ER3W	3	OBTEK	Motor Bracket Rail Screw Washer	R22 $\frac{1}{2}$ S	Not Shown	OCCDIS	Disc Lever Cam Screw
ER3 $\frac{1}{2}$	3	OBTTN	Motor Bracket Rail (Long)	R23A	3	OCCDOR	Name Plate
GR1	Not Shown	OBTOG	Hand Feed Gear and Pinion Guard	R23P	Not Shown	OCCDUM	Name Plate Pin
GR1S	Not Shown	OBTUS	Hand Feed Gear and Pinion Guard Screw	R23S	3	OCCEBI	Name Plate Screw
GR8	3	OBVAH	Disc Gear Guard	R26	1	OCCCEA	Fly Wheel
GR8S	Not Shown	OBVEY	Disc Gear Guard Screw	R26K	1	OCCEDY	Fly Wheel Key
GR63	3	OBVIT	Form Roller Guard	R27	1	OCCEFI	Roller Truck
GRF-1	2	OBVOL	Gear and Pinion Guard	R28L	3	OCCEGO	Chase Lug (Bottom)
GRF-1S	2	OBVUD	Gear and Pinion Guard Screw	R28LN	Not Shown	OCCCHS	Chase Lug Nut
R0	5	OBWAT	*Frame	R28LP	Not Shown	OCCCHA	Chase Lug Pin
R1A	4	OBWEX	Roller Arm Bracket	R28 $\frac{1}{2}$	4	OCCCKL	Chase
R1K	4	OBWIN	Roller Arm Bracket Key	R30	5	OCCCLI	Chase Hook
R1S	1	OBWOP	Roller Arm Bracket Screw (Short)	R30E	3	OCCCEMP	Chase Hook Lever Spring
R1SS	Not Shown	OBWUJ	Roller Arm Bracket Screw (Long)	R30H	5	OCCCENT	Chase Hook Lever Spring Hanger
R1W	Not Shown	OBXAC	Roller Arm Bracket Washer	R30L	5	OCCCEPU	Chase Hook Lever
R3	5	OBXEL	*Bed	R30LS	6	OCCERD	Chase Hook Lever Screw
R3TA	6	OBXIP	*Adjustable Bed Track, Left	R30N	5	OCCESA	Chase Hook Nut
R3TCS	6	OBXOR	Adjustable Bed Track Screw	R30S	5	OCCETH	Chase Hook Screw
R3TR	Not Shown	OBXUM	Adjustable Bed Track Chase Stop (Side)	R31	5	OCCEVIL	*Gripper Bar
R3TS	5	OBYAT	Adjustable Bed Track Adjusting Screw (Upper)	R31E	6	OCCCEWS	Gripper Bar Spring
R4A	5	OBYBU	*Platen	R31H	6	OCCCEXI	Gripper Bar Spring Hook
R4PL	10	OBYCK	Cutting Plate	R31P	Not Shown	OCCCEZA	Gripper Bar Pin
R4TA	5	OBYDO	*Adjustable Bed Track, Right	R32	5	OCCCFAB	Gripper Bar Roller
R4TS	5	OBYET	Adjustable Bed Track Adjusting Screw (Lower)	R32N	Not Shown	OCCCFEK	Gripper Bar Roller Screw Nut
R6	4	OBYFA	Rocker Lock	R32S	Not Shown	OCCCFIS	Gripper Bar Roller Screw
R6E	Not Shown	OBYGI	Rocker Lock Spring	R33	Not Shown	OCCCFOM	*Cam Roller
R6R	4	OBYHA	Rocker Lock Spring Rod	R33S	Not Shown	OCCCFUL	*Cam Roller Stud
R6SS	Not Shown	OBYID	Rocker Lock Set Screw	R33SN	Not Shown	OCCGAP	Cam Roller Stud Nut
R7 $\frac{1}{2}$	3	OBYJU	*Disc	R33T	5	OCCGES	Cam Roller Oil Tube
R7 $\frac{1}{2}$ S	Not Shown	OBYKA	Disc Stud	R33TC	Not Shown	OCCGIN	Cam Roller Oil Tube Clamp
R8A	3	OBYLE	Disc Bracket	R33TCP	Not Shown	OCCGUP	Cam Roller Oil Tube Clamp Pin
R8C	3	OBYMO	Disc Bracket Oil Cup	R36	9	OCCGUR	Disc Lever Cam Roller
R8S	1	OBYNS	Disc Bracket Screw	R36S	9	OCCCHAW	Disc Lever Cam Roller Stud
R8SW	Not Shown	OBYOM	Disc Bracket Washer	R36SC	Not Shown	OCCCHET	Disc Lever Cam Roller Stud Cotter
R10	3	OBYPB	Small Disc Gear	R37-1	9	OCCCHIF	*Adjustable Disc Lever
R10C	3	OBYRL	Small Disc Gear Lock	R37-1N	Not Shown	OCCCHOP	Adjustable Disc Lever Adjusting Screw Nut
R10CP	Not Shown	OBYSM	Small Disc Gear Lock Limit Pin	R37-1P	9	OCCCHUM	Adjustable Disc Lever Pin
R10E	Not Shown	OBYTU	Small Disc Gear Lock Spring	R37-1S	9	OCCCIBA	Adjustable Disc Lever Adjusting Screw
R10K	Not Shown	OBYUK	Small Disc Gear Key	R37-2	9	OCCCICE	Adjustable Disc Lever Link
R10P	Not Shown	OBYVI	Small Disc Gear Pin	R37-2N	Not Shown	OCCCIDI	Adjustable Disc Lever Link Stud Wing Nut
R10W	Not Shown	OBYWA	Small Disc Gear Washer	R37-2P	9	OCCCIFO	Adjustable Disc Lever Link Pin
R10 $\frac{1}{2}$	3	OBYXA	Disc Gear Sleeve	R37-2PC	Not Shown	OCCCIGU	Adjustable Disc Lever Link Pin Cotter
R10 $\frac{1}{2}$ B	Not Shown	OBYZO	Disc Gear Sleeve Ball	R37-2S	3	OCCCIHA	Adjustable Disc Lever Link Stud
R10 $\frac{1}{2}$ CA	3	OBZAL	Disc Gear Lock Collar	R37-2SW	Not Shown	OCCCIJU	Adjustable Disc Lever Link Stud Washer
R10 $\frac{1}{2}$ CASS	Not Shown	OBZES	Disc Gear Set Screw	R37-3	9	OCCCIKE	Adjustable Disc Lever Arm
R11	3	OBZIF	Large Disc Gear	R37-3P	Not Shown	OCCCILDL	Adjustable Disc Lever Arm Pin
R11K	Not Shown	OBZOR	Large Disc Gear Key	R37-4	9	OCCCIMF	Adjustable Disc Lever Bracket
R11LW	Not Shown	OBZUN	Large Disc Gear Lock Washer	R37-4S	Not Shown	OCCCINT	Adjustable Disc Lever Bracket Screw
R11S	Not Shown	OCABE	Large Disc Gear Screw	R37-4SS	Not Shown	OCCCIPS	Adjustable Disc Lever Bracket Set Screw
R11W	Not Shown	OCADU	Large Disc Gear Washer	R37-5	9	OCCCIRT	Adjustable Disc Lever Shaft
R12	6	OCAFI	Crank Shaft	R37-5LW	Not Shown	OCCCISA	Adjustable Disc Lever Shaft Lock Washer
R12B	5	OCAGL	Crank Shaft Bushing				

*Parts marked with an asterisk indicate special fitting and will be shipped with their mating part or parts.

IMPORTANT Be sure to mention size of press for which parts are being ordered.





COMPONENT PARTS LIST--Continued

Part Number	Part Shown on Plate No.	Code	Name and Description
R37-5S	Not Shown	OCITI	Adjustable Disc Lever Shaft Screw
R37-6	3	OCIVU	Adjustable Disc Lever Shaft Collar
R37-6SS	Not Shown	OCIWO	Adjustable Disc Lever Shaft Collar Set Screw
R38	9	OCIXI	*Silent Pawl Roller Cup
R38R	9	OCIYA	Silent Pawl Roller
R38W	9	OCIZE	Silent Pawl Retaining Plate
R38½	9	OCJAM	*Silent Pawl Roller Carrier
R38½EA	9	OCJEG	Silent Pawl Plunger Spring
R38½K	Not Shown	OCJIT	Silent Pawl Key
R38½PA	9	OCJOS	Silent Pawl Plunger
R39	1	OCJUZ	*Ink Roller Double Saddle
R39BB	3	OCKAR	Ink Roller Saddle Ball Bearing
R39C	Not Shown	OCKEJ	Ink Roller Saddle Rod Cotter
R39E	5	OCKIF	Ink Roller Saddle Spring
R39L	9	OCKOP	Ink Roller Saddle Lifter
R39P	3	OCKUN	Ink Roller Saddle Pin, Right
R39RP	Not Shown	OCLAS	Ink Roller Saddle Rod Pin
R39½P	1	OCLEY	Ink Roller Saddle Pin, Left
R40R	5	OCCLV	*Ink Roller Saddle Rod
R42	6	OCLOP	Rocker Box Cap
R42C	6	OCCLUB	Rocker Box Oil Cup
R42S	6	OCMAT	Rocker Box Screw
R43	6	OCMED	Crank Shaft Box
R43C	6	OCMIP	Crank Shaft Box Oil Cup
R43S	6	OCMOK	Crank Shaft Box Screw
R43W	Not Shown	OCMUB	Crank Shaft Box Washer
R45	1	OCNAF	*Ink Roller Saddle Stud
R45F	Not Shown	OCNEG	Ink Roller Saddle Stud Oil Packing
R45K	Not Shown	OCNIT	Ink Roller Saddle Stud Guide Key
R45W	2	OCNOS	Ink Roller Saddle Stud Packing Plate
R45WP	Not Shown	OCNUM	Ink Roller Saddle Stud Packing Plate Pin
R47	6	OCOBR	*Side Arm
R47B	Not Shown	OCOCA	Side Arm Bushing
R47C	4	OCODI	Side Arm Oil Cup
R47S	5	OCOFE	Side Arm Wrist Pin
R55A	6	OCOGU	Side Arm Washer
R55S	6	OCOHL	Side Arm Washer Screw
R61	9	OCOJI	Gripper Wrench
R62	Not Shown	OCOKU	Rocker Arm
R62P	Not Shown	OCOLD	Rocker Arm Pin
R63	10	OCOMA	*Roller Stock
R63B	Not Shown	OCONT	Roller Stock Steel Ball
R63E	Not Shown	OCOPE	Roller Stock Ball Spring
R64	6	OCORP	Tympan Bale, Upper
R64L	9	OCOSK	Tympan Bale Lifter
R64R	5	OCOTH	Tympan Bale Rivet
R64½	5	OCOVR	Tympan Bale, Lower
R65A	6	OCOWL	Platen Ear, Left
R65P	Not Shown	OCOXE	Platen Ear Pin
R65S	Not Shown	OCOYA	Platen Ear Screw
R66	5	OCOZO	Platen Ear, Right
R67	5	OCPAF	*Gripper Cam
R67P	6	OCPEM	Gripper Cam Pin
R67PSS	Not Shown	OCPID	Gripper Cam Pin Set Screw
R68	5	OCPOX	Main Shaft
R68B	4	OCPUF	Main Shaft Bushing
R68BP	Not Shown	OCQAW	Main Shaft Bushing Pin
R68C	4	OCQED	Main Shaft Oil Cup
R68K	5	OCQIT	Main Shaft Key
R69	5	OCQOB	Back Shaft
R69C	5	OCQUA	Back Shaft Oil Cup
R70	3	OCRAN	Throw-Off Saddle
R70K	Not Shown	OCREK	Throw-Off Saddle Key
R70SS	Not Shown	OCRIL	Throw-Off Saddle Set Screw
R71L	3	OCROP	Back Shaft Collar (Left)
R71R	3	OCRUS	Back Shaft Collar (Right)
R71SS	Not Shown	OCSAP	Back Shaft Collar Set Screw
R72	6	OCSEK	Throw-Off Back Connection
R72N	Not Shown	OCSIN	Throw-Off Back Connection Nut
R72S	3	OCSOR	Throw-Off Back Connection Screw
R72SC	Not Shown	OCSUT	Throw-Off Back Connection Screw Cotter
R72½A	6	OCTAV	Throw-Off Lower Connection
R72½S	6	OCTEL	Throw-Off Lower Connection Screw
R72½SN	Not Shown	OCITIN	Throw-Off Lower Connection Screw Nut
R73A	3	OCOTR	Throw-Off Slotted Piece
R76A	3	OCUUF	Throw-Off Outer Arm
R76P	3	OCUBA	Throw-Off Outer Arm Pin
R76PC	Not Shown	OCUCH	Throw-Off Outer Arm Pin Cotter
R76S	6	OCUDS	Throw-Off Outer Arm Screw

Part Number	Part Shown on Plate No.	Code	Name and Description
R76SN	Not Shown	OCUF1	Throw-Off Outer Arm Screw Nut
R78A	8	OCUGS	*Throw-Off Lever
R78B	8	OCUHL	Throw-Off Lever Bushing
R78BA	8	OCUJO	Throw-Off Lever Latch Bushing
R78C	8	OCUKE	Throw-Off Lever Oil Cup
R78GA	8	OCULP	Throw-Off Sliding Bar Gib
R78GS	Not Shown	OCUMB	Throw-Off Sliding Plate Gib Screw
R78GSW	Not Shown	OCUNT	Throw-Off Sliding Plate Gib Screw Washer
R78L	8	OCUPA	Throw-Off Lever Latch
R78LC	8	OCURT	Throw-Off Lever Connection
R78LP	8	OCUSP	Throw-Off Lever Latch Pin
R78LPC	Not Shown	OCUTI	Throw-Off Lever Latch Pin Cotter
R78P	8	OCUVE	*Throw-Off Lever Shear Pin
R78PS	8	OCUWL	Throw-Off Lever Shear Pin Swivel
R78PSS	8	OCUXI	Throw-Off Lever Shear Pin Swivel Set Screw
R78SAA	8	OCUYN	Throw-Off Lever Screw
R78SN	8	OCUZO	Throw-Off Lever Screw Nut
R78½A	8	OCVAP	Throw-Off Lever Shear Pin Latch Lever
R78½S	8	OCVEM	Throw-Off Lever Shear Pin Latch Lever Pin
R79A	4	OCVID	Throw-Off Lever Bracket
R79S	Not Shown	OCVOT	Throw-Off Lever Bracket Screw
R79SS	Not Shown	OCVUX	Throw-Off Lever Bracket Set Screw
R79SSN	Not Shown	OCWAN	Throw-Off Lever Bracket Set Screw Nut
R79SW	Not Shown	OCWET	Throw-Off Lever Bracket Screw Washer
R80	6	OCWIP	Gripper, Left
R80C	9	OCWOF	Extension Gripper, Left
R80CA	9	OCWUB	Gripper Extension 1" long
R80CB	9	OCXAB	Gripper Extension 2" long
R80CD	9	OCXEL	Gripper Extension 3" long
R80CE	9	OCXIP	Gripper Extension 4" long
R80CF	9	OCXOF	Gripper Extension Finger
R80N	5	OCXUM	Gripper Nut
R80S	6	OCYAB	Gripper Bolt
R81	6	OCYES	Gripper, Right
R81C	9	OCYIL	Extension Gripper, Right
R83	10	OCYON	*Hand Feed Table
R83S	Not Shown	OCYUC	Hand Feed Table Screw
R85L	9	OCZAL	Fountain Side Frame, Left
R85N	9	OCZED	Fountain Side Frame Cap Screw Nut
R85R	9	OCZIM	Fountain Side Frame, Right
R85S	3	OCZOP	Fountain Adjusting Screw
R85SN	3	OCZUD	Fountain Adjusting Screw Wing Nut
R85T	9	ODABE	Fountain Thumb Screw
R85½	9	ODACH	*Fountain Ink Roll
R85½B	Not Shown	ODADS	Fountain Ink Roll Bushing
R86C	Not Shown	ODAFI	Fountain Side Frame Oil Cup
R86L	9	ODAGU	Fountain Side Frame Cap, Left
R86NP	Not Shown	ODAHL	Fountain Side Frame Cap Screw Pin
R86P	Not Shown	ODAJE	Fountain Side Frame Cap Dowel Pin
R86R	9	ODAKU	Fountain Side Frame Cap, Right
R86S	Not Shown	ODALP	Fountain Side Frame Cap Screw
R87	3	ODAMF	Fountain Bracket
R87S	Not Shown	ODANT	Fountain Bracket Screw
R87½	9	ODAPR	Fountain Cover
R87½L	Not Shown	ODARB	Fountain Cover Latch
R87½R	Not Shown	ODASK	Fountain Cover Rivet
R88	9	ODATA	Fountain Ratchet Lever
R88P	9	ODAVE	Fountain Ratchet Lever Pin
R88½	3	ODAWN	Fountain Ratchet Lever Rod
R88½E	Not Shown	ODAXU	Fountain Ratchet Lever Rod Spring
R89	9	ODAYM	Fountain Ratchet
R89K	Not Shown	ODAZL	Fountain Ratchet Key
R89½	9	ODBAN	Fountain Ink Blade
R89½S	Not Shown	ODBER	Fountain Ink Blade Screw
R90	9	ODBIT	Fountain Ratchet Pawl
R90S	9	ODBOS	Fountain Ratchet Pawl Screw
R90½	3	ODBUM	Fountain Driver
R90½S	Not Shown	ODCAN	Fountain Driver Screw
R90½SC	Not Shown	ODCEH	Fountain Driver Screw Cotter
R91	9	ODCIJ	Fountain Adjusting Block
R92	Not Shown	ODCOP	Fountain Cover Knob
R92½	9	ODCUT	Fountain Handwheel
R92½P	Not Shown	ODDAM	Fountain Handwheel Pin
R93	9	ODDEZ	Fountain Front Brace
R93S	Not Shown	ODDIK	Fountain Front Brace Screw
R93½	Not Shown	ODDOL	Fountain Back Separator Rod
R93½S	Not Shown	ODDUF	Fountain Back Separator Rod Screw
R94A	6	ODEBA	Throw-Off Outer Arm Stud
R94N	Not Shown	ODECI	Throw-Off Outer Arm Stud Nut



*Parts marked with an asterisk indicate special fitting and will be shipped with their mating part or parts.
IMPORTANT Be sure to mention size of press for which parts are being ordered.

COMPONENT PARTS LIST—Continued

Part Number	Part Shown on Plate No.	Code	Name and Description	Part Number	Part Shown on Plate No.	Code	Name and Description
R94NW	Not Shown	ODEDU	Throw-Off Outer Arm Stud Washer	RF-5A	1	ODMOL	Feeder Drive Gear Guard
R94SS	Not Shown	ODEFT	Throw-Off Outer Arm Stud Set Screw	RF-6	2	ODMUY	Feeder Drive Gear Guard Brace
R95	10	ODEGA	Motor Belt	RF-6S	2	ODNAD	Feeder Drive Gear Guard Brace Screw
R96A	5	ODEHL	Bed Shaft	RF-8	Not Shown	ODNEP	Feed Table Lock Screw Shoe
R96B	Not Shown	ODEJO	Bed Shaft Bushing	RF-9	7	ODNIB	Feed Table Lock Screw
R96C	5	ODEKS	Bed Shaft Collar	RF-9N	7	ODNOF	Feed Table Lock Screw Nut
R96CSS	Not Shown	ODELM	Bed Shaft Collar Set Screw	RF-10AA	7	ODNUH	Feed Table Bracket
R96K	Not Shown	ODEMT	Bed Shaft Key	RF-10G	7	ODOBS	Feed Table Bracket Gasket
R96SS	Not Shown	ODENK	Bed Shaft Set Screw	RF-10T	2	ODOCK	Feed Table Pinion Shaft Oil Tube
R96T	5	ODEPS	Bed Shaft Oil Tube	RF-11	4	ODODR	Feed Table Stationery Rail
R96TC	Not Shown	ODERK	Bed Shaft Oil Tube Clamp	RF-12	4	ODOFT	Feed Table Movable Rail
R96TCP	Not Shown	ODESL	Bed Shaft Oil Tube Clamp Pin	RF-13	7	ODOGI	Feed Table Adjusting Screw
R97	9	ODETU	Fountain Front Brace Rod	RF-13W	Not Shown	ODOHT	Feed Table Adjusting Screw Washer
R97S	Not Shown	ODEVL	Fountain Front Brace Rod Screw	RF-15	7	ODOJ1	Feed Table Raising Handwheel
R98	6	ODEWP	Rocker Lock Shaft	RF-15P	Not Shown	ODOKA	Feed Table Raising Handwheel Pin
R98B	6	ODEXA	Rocker Lock Shaft Bushing	RF-16	7	ODOLF	Feed Table Release Ratchet Stop
R98BSS	Not Shown	ODEYI	Rocker Lock Shaft Bushing Set Screw	RF-18A	2	ODOMB	Feed Table Bracket Guard
R99	4	ODEZE	Name Plate	RF-18S	Not Shown	ODONT	Feed Table Bracket Guard Screw
R99P	Not Shown	ODFAQ	Name Plate Pin	RF-19	7	ODOPH	*Feed Table Long Back Stop
R99½	Not Shown	ODFEW	Fountain Name Plate	RF-19P	Not Shown	ODORI	Feed Table Long Back Stop Taper Pin
R99½P	Not Shown	ODFIV	Fountain Name Plate Pin	RF-19S	Not Shown	ODOSM	Feed Table Long Back Stop Screw
R-100A	6	ODFOS	Bed Shaft Adjusting Arm	RF-20A	7	ODOTU	Feed Table Long Back Stop Bracket
R-100SN	6	ODFUR	Bed Shaft Adjusting Arm Set Screw Nut	RF-20S	7	ODOVL	Feed Table Long Back Stop Bracket Clamping Screw
R-100SS	6	ODGAS	Bed Shaft Adjusting Arm Set Screw	RF-21	1	ODOWN	Feed Table Long Back Stop Post
R-101	6	ODGED	Bed Shaft Adjusting Screw Swivel Pin	RF-21SS	Not Shown	ODOXA	Feed Table Long Back Stop Post Set Screw
R-104	3	ODGIF	Bed Shaft Adjusting Screw	RF-22	7	ODOYT	Feed Table Long Back Stop Limit Pin
R-104C	3	ODGOL	Bed Shaft Adjusting Collar	RF-22	7	ODOZN	Feed Table Long Back Stop Limit Pin Lock Nut
R-104CP	Not Shown	ODGUP	Bed Shaft Adjusting Collar Pin	RF-25A	7	ODPAC	Feed Table Short Back Stop
R-104CSS	Not Shown	ODHAM	Bed Shaft Adjusting Collar Pin Set Screw	RF-26A	7	ODPEW	Feed Table Short Back Stop Clamp Screw
R-105	3	ODHEN	Bed Shaft Adjusting Screw Handwheel	RF-27A	Not Shown	ODPIN	Feed Table Short Back Stop Clamp Screw Nut
R-105P	Not Shown	ODHIP	Bed Shaft Adjusting Screw Handwheel Pin	RF-28A	Not Shown	ODPOB	Feed Table Short Back Stop Clamp Screw Spring
R-106A	Not Shown	ODHOR	*Bed Shaft Adjusting Tube	RF-30AA	7	ODPUG	*Feed Table Front Stop
R-107	Not Shown	ODHUS	Bed Shaft Adjusting Tube Bushing	RF-30S	2	ODQAF	Feed Table Front Stop Screw
R-107P	Not Shown	ODIBA	Bed Shaft Adjusting Tube Bushing Pin	RF-32A	7	ODQEB	Feed Table Front Stop Blast Tubing
R-108	3	ODICT	Bed Shaft Adjusting Screw Bracket	RF-33A	7	ODQIG	*Feed Table Front Stop Blast Nipple
R-108SS	Not Shown	ODIDE	Bed Shaft Adjusting Screw Bracket Set Screw	RF-34A	Not Shown	ODQOH	Feed Table Front Stop Blast Nipple Tube
R-109	6	ODIFR	Bed Shaft Adjusting Scale Pointer	RF-37A	7	ODQUI	*Feed Table Front Stop End Blast Connection
R-109S	6	ODIGS	Bed Shaft Adjusting Scale Pointer Screw	RF-38A	7	ODRAT	*Feed Table Front Stop End Blast Shut-Off
R-110	6	ODIHT	Bed Shaft Adjusting Screw Swivel Bracket	RF-38E	7	ODREM	Feed Table Front Stop End Blast Shut-Off Spring
R-110P	Not Shown	ODIJA	Bed Shaft Adjusting Screw Swivel Bracket Pin	RF-38W	Not Shown	ODRIK	Feed Table Front Stop End Blast Shut-Off Washer
R-110S	Not Shown	ODIKE	Bed Shaft Adjusting Screw Swivel Bracket Screw	RF-39	5	ODROF	*Delivery Air Line Screen
R-111	5	ODILF	Back Shaft Adjusting Screw Swivel Pin	RF-39BA	Not Shown	ODRUP	*Delivery Air Line Screen Bushing
R-113	5	ODIMP	Back Shaft Adjusting Screw Lock Screw	RF-39P	Not Shown	ODSAP	*Delivery Air Line Screen Plug
R-113P	Not Shown	ODING	Back Shaft Adjusting Screw Lock Screw Shoe	RF-40	2	ODSEB	*Delivery Slide Air Tube
R-115	5	ODIPH	Back Shaft Adjusting Screw Knob	RF-40P	Not Shown	ODSIC	*Delivery Slide Air Tube Plug
R-115P	Not Shown	ODIRT	Back Shaft Adjusting Screw Knob Pin	RF-41	9	ODSON	*Delivery Bar
R-116	3	ODISH	Bed Shaft Adjusting Screw Swivel Pin	RF-41S	9	ODSUM	*Delivery Bar Screw
R-116N	Not Shown	ODITS	Bed Shaft Adjusting Screw Swivel Nut	RF-43	9	ODTAC	*Delivery Bar Sliding Tube
R-116S	3	ODIVA	Bed Shaft Adjusting Screw Swivel Screw	RF-43S	9	ODTED	*Delivery Bar Sliding Tube Screw
R-116W	Not Shown	ODIWU	Bed Shaft Adjusting Screw Swivel Washer	RF-45	1	ODTIG	Delivery Slide Shaft
R-119A	5	ODIXE	Back Shaft Adjusting Screw	RF-47	2	ODTOK	Delivery Slide Air Tube Roller Carrier
R-119N	Not Shown	ODIYL	Back Shaft Adjusting Screw Nut	RF-47S	2	ODTUR	Delivery Slide Air Tube Roller Carrier Clamp Screw
R-119W	Not Shown	ODIZY	Back Shaft Adjusting Screw Washer	RF-49	5	ODUBL	Delivery Bar Pull-In Spring
R-122	4	ODJAK	Press Pulley	RF-49P	5	ODUCH	Delivery Bar Pull-In Spring Pin
R-125A	5	ODJEM	Back Shaft Eccentric	RF-49PC	Not Shown	ODUDI	Delivery Bar Pull-In Spring Pin Cotter
R-126AA	5	ODJIX	Back Shaft Eccentric Bracket	RF-50	5	ODUFT	*Delivery Slide
R-126P	5	ODJOG	Back Shaft Eccentric Bracket Swivel Pin	RF-50B	Not Shown	ODUGS	Delivery Slide Bushing
R-126S	5	ODJUF	Back Shaft Eccentric Bracket Swivel Pin Set Screw	RF-50P	2	ODUHM	Delivery Slide Bushing Spring Pin
R-126SS	3	ODKAT	Back Shaft Eccentric Set Screw	RF-50T	5	ODUJE	Delivery Slide Oil Tube
R-126SSN	3	ODKER	Back Shaft Eccentric Set Screw Lock Nut	RF-50TC	5	ODUKA	Delivery Slide Oil Tube Clamp
R-126SW	Not Shown	ODKIF	Back Shaft Eccentric Bracket Swivel Pin Set Screw Washer	RF-50TCS	Not Shown	ODULK	Delivery Slide Oil Tube Clamp Screw
R-130A	5	ODKOB	Back Shaft Adjusting Scale Pointer	RF-51	5	ODUMF	Feeder Ball Bearing Cam Roller
R-130S	Not Shown	ODKUC	Back Shaft Adjusting Scale Pointer Screw	RF-52	5	ODUNT	Feeder Ball Bearing Cam Roller Pin
R-131A	5	ODLAS	Back Shaft Adjusting Scale	RF-53A	2	ODUPO	*Delivery Slide Shoe
R-131P	Not Shown	ODLET	Back Shaft Adjusting Scale Pin	RF-53SS	2	ODURB	Delivery Slide Shoe Set Screw
RF-1A	4	ODLIC	Feeder Cam Shaft Bracket	RF-54A	5	ODUSC	Delivery Slide Shoe Gib
RF-1C	Not Shown	ODLOB	Feeder Cam Shaft Bracket Oil Cup	RF-55A	5	ODUTE	Delivery Slide Shoe Gib Screw
RF-1S	Not Shown	ODLUN	Feeder Cam Shaft Bracket Screw	RF-55N	5	ODUVR	Delivery Slide Shoe Gib Screw Nut
RF-2	4	ODMAG	Feed Table Elevator Shaft Bracket	RF-56	5	ODUWE	Delivery Bar Pull Down Spring
RF-2S	Not Shown	ODMEX	Feed Table Elevator Shaft Bracket Screw	RF-57A	2	ODUXI	Delivery Slide Hose Nipple
RF-3	Not Shown	ODMIN	Feed Table Elevator Cam Lever Spring Pin				

*Parts marked with an asterisk indicate special fitting and will be shipped with their mating part or parts.

IMPORTANT:—Be sure to mention size of press for which parts are being ordered.






PLATE Nº 7

COMPONENT PARTS LIST--Continued

Part Number	Part Shown on Plate No.	Code	Name and Description	Part Number	Part Shown on Plate No.	Code	Name and Description
RF-57S	2	ODUYA	Delivery Slide Hose Nipple Clamp Screw	RF-141A	4	OFERM	*Blast Valve Cam Lever
RF-58	2	ODUZO	Delivery Slide Air Hose	RF-144A	1	OFESY	Blast Valve Plunger
RF-60	5	ODVAP	Delivery Slide Air Tube Lift Lever	RF-144E	1	OFETH	Blast Valve Plunger Spring
RF-64	5	ODVEC	Delivery Slide Air Tube Lift Lever Spring	RF-144EH	1	OFEVA	Blast Valve Plunger Spring Connection
RF-65	5	ODVIM	Delivery Slide Air Tube Lift Lever Stud	RF-145	8	OFEWT	Continuous Blast Screw
RF-68	9	ODVOH	Feed Bar Large Rubber Sucker Tip	RF-146	8	OFEXE	Continuous Blast Screw Lock Nut
RF-69	5	ODVUF	*Feed Air Line Screen	RF-147	1	OFEYR	Blast Valve Plunger Spring Stud
RF-69B	Not Shown	ODWAX	*Feed Air Line Screen Bushing	RF-147CP	Not Shown	OFEZO	Blast Valve Plunger Spring Stud Cotter
RF-70	2	ODWEZ	*Feed Slide Air Tube	RF-147W	Not Shown	OFFAB	Blast Valve Plunger Spring Stud Washer
RF-70P	Not Shown	ODWIV	*Feed Slide Air Tube Plug	RF-150A	4	OFFEC	Feed Table Elevator Cam
RF-70S	Not Shown	ODWOY	*Feed Slide Air Tube Plug Screw	RF-150SS	Not Shown	OFFID	Feed Table Elevator Cam Set Screw
RF-71	1	ODWUF	Feed Slide Air Hose	RF-151	7	OFFOJ	Feed Table Elevator Shaft
RF-72	1	ODXAR	Feed Slide Air Tube Roller Carrier	RF-152	4	OFFUT	*Feed Table Elevator Shaft Cam Lever
RF-72CP	Not Shown	ODXEY	Feed Slide Air Tube Roller Carrier Cotter	RF-152E	Not Shown	OFGAX	Feed Table Elevator Shaft Cam Lever Spring
RF-72S	1	ODXIT	Feed Slide Air Tube Roller Carrier Clamp Screw	RF-152H	Not Shown	OFGEH	Feed Table Elevator Shaft Cam Lever Spring Pin
RF-74	1	ODXON	Feed Slide Air Tube Pull Down Spring	RF-152K	Not Shown	OFGIN	Feed Table Elevator Shaft Cam Lever Key
RF-75	1	ODXUP	*Feed Slide	RF-152P	Not Shown	OFGOP	Feed Table Elevator Shaft Cam Lever Roller Pin
RF-75T	1	ODYAB	*Feed Slide Oil Tube	RF-153	4	OFGUB	Feed Table Elevator Shaft Cam Lever Roller
RF-78	1	ODYEC	*Feed Slide Shoe	RF-160AA	7	OFHAT	Feed Table
RF-78SS	1	ODYID	Feed Slide Shoe Set Screw	RF-161A	7	OFHEC	Feed Table Rack
RF-80	5	ODYOF	Feed Slide Air Tube Lift Lever	RF-161K	Not Shown	OFHIS	Feed Table Rack Key
RF-84	1	ODYUG	Feed Slide Hose Nipple	RF-161W	2	OFHOP	Feed Table Bumper Washer
RF-84S	1	ODZAH	Feed Slide Hose Nipple Clamp Screw	RF-162AA	7	OFHUG	Feed Table Front Bar
RF-86A	5	ODZEJ	*Feed Bar Air Tube Connection	RF-162P	Not Shown	OFIBR	Feed Table Front Bar Taper Pin
RF-86N	5	ODZIK	Feed Bar Limit Screw Nut	RF-162S	Not Shown	OFICL	Feed Table Front Bar Screw
RF-86S	5	ODZOL	Feed Bar Limit Screw	RF-165	7	OFIDO	Feed Table Adjusting Screw Crank
RF-87	Not Shown	ODZUM	*Feed Bar Air Tube Connection Plug	RF-165SS	Not Shown	OFIFE	Feed Table Adjusting Screw Set Screw
RF-95A	5	OFABS	Feed and Delivery Slide Spring Bracket	RF-168AA	7	OFIGA	Feed Table Pinion Shaft
RF-95S	5	OFACT	Feed and Delivery Slide Spring Bracket Screw	RF-169	7	OFIHM	*Feed Table Pinion
RF-100	2	OFADA	Delivery Air Valve Bracket	RF-169K	Not Shown	OFIKE	Feed Table Pinion Key
RF-100S	Not Shown	OFAPR	Delivery Air Valve Bracket Screw	RF-170A	1	OFILS	Feed Table Guide Finger Bracket, Right
RF-101	2	OFAGL	*Delivery Air Valve Cam Lever	RF-170S	1	OFIMT	Feed Table Guide Finger Bracket Screw
RF-101W	Not Shown	OFAHN	Delivery Air Valve Cam Lever Spacing Washer	RF-171A	1	OFING	Feed Table Guide Finger Bracket, Left
RF-102	4	OFAJU	Delivery Air Valve Cam Roller Pin	RF-172	1	OFIPU	*Feed Table Guide Finger
RF-103	4	OFAKL	Delivery Air Valve Cam Roller	RF-172S	1	OFIRE	Feed Table Guide Finger Screw
RF-104	Not Shown	OFALT	Delivery Air Valve Cam Lever Shaft	RF-173	7	OFISH	Feed Table Guide Finger Shaft
RF-105A	4	OFAMB	Delivery Air Valve Cam	RF-173CP	Not Shown	OFITS	Feed Table Guide Finger Shaft Cotter
RF-105SS	Not Shown	OFAND	Delivery Air Valve Cam Set Screw	RF-173SS	Not Shown	OFIVU	Feed Table Guide Finger Shaft Set Screw
RF-106	8	OFAPH	Delivery Air Valve Bracket Pipe Elbow	RF-175	7	OFIWO	*Feed Table Release Handle
RF-107	8	OFARQ	Delivery Air Valve Bracket Pipe Short Nipple	RF-176	1	OFIXU	Feed Table Release Handle Pin
RF-108	8	OFAST	Delivery Air Valve Bracket Pipe Long Nipple	RF-177	1	OFIYA	Feed Table Release Handle Swivel Pin
RF-109A	4	OFATU	Delivery Cutout Valve Cam	RF-180	7	OFIZL	Feed Table Worm
RF-110	2	OFAVY	*Delivery Cutout Valve Cam Lever	RF-180K	Not Shown	OFJAZ	Feed Table Worm Key
RF-113	8	OFAWL	*Delivery Cutout Valve	RF-182	Not Shown	OFJER	Feed Table Ratchet Wheel Sleeve
RF-113P	Not Shown	OFAXO	Delivery Cutout Valve Cotter	RF-185	7	OFJIG	Feed Table Ratchet Wheel
RF-113S	Not Shown	OFAYE	Delivery Cutout Valve Screw	RF-185K	Not Shown	OFJOB	Feed Table Ratchet Wheel Key
RF-114	8	OFAZL	Delivery Cutout Valve Plunger	RF-187	2	OFJUS	Feed Table Ratchet Pawl
RF-115	8	OFBAN	Delivery Cutout Valve Plunger Spring	RF-187P	2	OFKAN	Feed Table Ratchet Pawl Pin
RF-115½	2	OFBEG	Delivery Air Valve	RF-187E	7	OFKEB	Feed Table Ratchet Pawl Spring
RF-115½C	Not Shown	OFBIP	*Delivery Air Valve Cotter	RF-187ES	Not Shown	OFKIP	Feed Table Ratchet Pawl Spring Screw
RF-116	8	OFBOX	Delivery Cutout Valve Hose Nipple	RF-188A	1	OFKOF	*Feed Table Ratchet Pawl Lever
RF-117	2	OFBUR	Delivery Cutout Valve Air Hose	RF-188SS	Not Shown	OFKUD	Feed Table Ratchet Pawl Spring Screw
RF-119	Not Shown	OFBIB	Blast Muffler Nipple	RF-188W	Not Shown	OFLAM	Feed Table Ratchet Pawl Spring Washer
RF-120A	1	OFBIB	Blast Muffler Nipple	RF-189	2	OFLAM	Feed Table Ratchet Latch Stud
RF-120S	Not Shown	OFBIB	Blast Muffler Nipple	RF-189CP	Not Shown	OFLIZ	Feed Table Ratchet Latch Pin Cotter
RF-121	4	OFBIB	Blast Muffler Nipple	RF-189W	Not Shown	OFLIZ	Feed Table Ratchet Latch Pin Cotter Washer
RF-121SS	Not Shown	OFBIB	Blast Muffler Nipple	RF-190A	2	OFLUW	Feed Table Ratchet Pawl Latch
RF-121SSN	Not Shown	OFBIB	Blast Muffler Nipple	RF-195A	2	OFLUW	Feed Slide Air Tube Raising Cam
RF-122	8	OFDEY	Feed Table Blast Hose	RF-196A	4	OFMEN	Feed Slide Pushout Cam
RF-122C	8	OFDIJ	Feed Table Blast Hose Clamp	RF-197A	4	OFMIS	Delivery Slide Air Tube Raising Cam
RF-124	Not Shown	OFDON	Feed Air Valve Cam Lever Shaft	RF-198A	4	OFMOT	Delivery Slide Pushout Cam
RF-125A	4	OFDUL	Feed Air Valve Cam	RF-199A	4	OFMUK	*Feeder Cam Shaft
RF-126A	8	OFEBY	*Blast Muffler	RF-199KA	5	OFNAG	Feeder Cam Shaft Key
RF-127A	1	OFECT	*Blast Muffler Plate	RF-200A	6	OFNET	Feeder Drive Gear
RF-130	1	OFEDA	Feed Starting Lever Bracket	RF-200KA	6	OFNIC	Feeder Drive Gear Key
RF-133	1	OFEFI	*Feed Starting Lever	RF-202A	4	OFNOB	*Feeder Drive Intermediate Gear
RF-134	1	OFEGL	Feed Starting Lever Latch Pin	RF-203A	Not Shown	OFNUM	Feeder Drive Intermediate Gear Shaft
RF-134CP	Not Shown	OFEHR	Feed Starting Lever Latch Pin Cotter	RF-203C	4	OFOBA	Feeder Drive Intermediate Gear Shaft Oil Cup
RF-134W	Not Shown	OFEJY	Feed Starting Lever Latch Pin Washer	RF-203S	4	OFOCE	Feeder Drive Intermediate Gear Shaft Screw
RF-136	1	OFEKU	Feed Starting Lever Latch	RF-205A	Not Shown	OFODI	Feeder Drive Intermediate Gear Bushing
RF-137	1	OFEKN	Blast Valve Connection	RF-206	4	OFOGU	Feeder Drive Intermediate Gear Bracket
RF-138	1	OFEMA	Blast Adjusting Screw	RF-207A	7	OFOHA	*Feed Table Stripper Wire Bracket
RF-139	1	OFENS	Blast Adjusting Screw Nut	RF-207N	7	OFOJY	Feed Table Stripper Wire Bracket Lock Nut
RF-140A	4	OFEPU	Blast Valve Cam				

*Parts marked with an asterisk indicate special fitting and will be shipped with their mating part or parts.
IMPORTANT Be sure to mention size of press for which parts are being ordered.

COMPONENT PARTS LIST---Continued

Part Number	Part Shown on Plate No.	Code	Name and Description	Part Number	Part Shown on Plate No.	Code	Name and Description
RF-207S	Not Shown	OFOKI	Feed Table Stripper Wire Bracket Screw	RF-271A	7	OFZIF	Delivery Table Rear Jogger Post
RF-2091	7	OFOFK	Feed Table Stripper Wire	RF-271P	Not Shown	OFZOR	Delivery Table Rear Jogger Stop Pin
RF-210A	7	OFOMT	Feed Table Stripper Wire Clamp Screw	RF-271S	7	OFZUN	Delivery Table Rear Jogger Post Screw
RF-210W	Not Shown	OFOFY	Feed Table Stripper Wire Clamp Screw Washer	RF-271W	7	OGABE	Delivery Table Rear Jogger Post Washer
RF-211	7	OFOPR	Feed Table Stripper Wire Bracket Shaft	RF-271WS	Not Shown	OGACI	Delivery Table Rear Jogger Post Washer Screw
RF-211CP	Not Shown	OFORK	Feed Table Stripper Wire Bracket Shaft Spring Cotter	RF-272AA	7	OGADO	Delivery Table Rear Jogger Operating Shaft
RF-212	7	OFOSQ	Feed Table Feeler Spring	RF-272E	7	OGAFU	Delivery Table Rear Jogger Operating Shaft Spring
RF-213A	7	OFOQA	Feed Table Feeler	RF-272ES	Not Shown	OGAGY	Delivery Table Rear Jogger Operating Shaft Spring Screw
RF-213SS	Not Shown	OFOVI	Feed Table Feeler Set Screw	RF-273	7	OGAHR	Delivery Table Rear Jogger Guide Rod
RF-215A	7	OFOWP	Feed Table Feeler Shaft Stop Collar	RF-273SS	Not Shown	OGAJA	Delivery Table Rear Jogger Guide Rod Set Screw
RF-215SS	Not Shown	OFOX	Feed Table Feeler Shaft Stop Collar Set Screw	RF-279AA	4	OGAKR	Delivery Table Jogger Cam Lever
RF-217A	7	OFOYD	*Feed Table Feeler Lift Rod	RF-280AA	4	OGALP	Delivery Table Jogger Cam Lever Screw
RF-217P	Not Shown	OFOZE	Feed Table Feeler Lift Rod Spring Pin	RF-280N	4	OGAMB	Delivery Table Jogger Cam Lever Screw Nut
RF-218A	Not Shown	OFPAD	*Feed Table Feeler Lift Rod End	RF-281	4	OGANT	Delivery Table Jogger Cam Lever Roller
RF-220AA	7	OFPEB	Feed Table Feeler Shaft	RF-282	6	OGAPL	Delivery Table Jogger Cam Lever Roller Pin
RF-220C	7	OFPIQ	Feed Table Feeler Shaft Collar	RF-288	8	OGARD	Throw-Off Plunger
RF-220CSS	Not Shown	OFPOK	Feed Table Feeler Shaft Collar Set Screw	RF-288P	8	OGAST	*Throw-Off Plunger Pin
RF-222A	7	OFPUZ	Feed Table Feeler Trip	RF-289	8	OGATH	Throw-Off Plunger Spring
RF-222AS	Not Shown	OFRAF	Feed Table Feeler Trip Screw	RF-291AA	6	OGAVR	*Throw-Off Sliding Bar
RF-222SS	Not Shown	OFREK	Feed Table Feeler Trip Set Screw	RF-291B	Not Shown	OGAWK	Throw-Off Sliding Bar Bushing
RF-222SSN	Not Shown	OFRIB	Feed Table Feeler Trip Set Screw Nut	RF-291S	6	OGAXO	Throw-Off Sliding Bar Stud
RF-225	4	OFRIO	Delivery Table Bracket	RF-292	8	OGAYF	*Throw-Off Sliding Bar Guide
RF-225S	4	OFRUN	Delivery Table Bracket Screw	RF-293	Not Shown	OGAZU	Throw-Off Sliding Bar Guide Pin
RF-226A	7	OFSDA	Delivery Table Post	RF-298	8	OGBAC	Throw-Off Rubber Hose
RF-230AA	7	OFSEZ	*Delivery Table	RF-300	8	OGBED	Pump Cylinder
RF-230SS	2	OFSIK	Delivery Table Set Screw	RF-301	8	OGBIF	*Pump Top
RF-232	7	OFSON	Delivery Table Jogger Plate, Right	RF-301S	8	OGBOG	Pump Top Screw
RF-233	7	OFSUR	Feed Table Short Back Stop Plate	RF-302B	8	OGBUH	Pump Top Bushing
RF-235A	7	OFTAC	Delivery Table Locking Pin	RF-302BSS	8	OGCAJ	Pump Top Bushing Set Screw
RF-235CP	Not Shown	OFTEB	Delivery Table Locking Pin Cotter	RF-302G	8	OGCEK	Pump Top Gland
RF-235E	1	OFTIP	Delivery Table Locking Pin Spring	RF-302N	8	OGCIL	Pump Top Gland Nut
RF-235W	Not Shown	OFTOD	Delivery Table Locking Pin Washer	RF-302NSS	8	OGCOM	Pump Gland Nut Set Screw
RF-236	1	OFTUF	Feed Starting Lever Screw	RF-303A	8	OGCUN	*Pump Base
RF-236N	Not Shown	OFUBA	Feed Starting Lever Screw Nut	RF-303S	8	OGDAP	Pump Base Screw
RF-240A	7	OFUCE	Feed Table Elevator Adjusting Screw Bracket	RF-307A	8	OGDEQ	*Pump Piston
RF-240E	7	OFUDI	Feed Table Elevator Adjusting Screw Spring	RF-307E	8	OGDIR	Pump Piston Expanding Spring
RF-240S	7	OFUFT	Feed Table Elevator Adjusting Screw	RF-307P	8	OGDOS	Pump Piston Rod Packing
RF-240SS	Not Shown	OFUGO	Feed Table Elevator Adjusting Screw Bracket Set Screw	RF-307W	8	OGDUT	Pump Piston Leather Ring
RF-242A	7	OFUHL	Feed Table Elevator Trip Trigger	RF-308	8	OGEBI	*Pump Valve
RF-243	1	OFUJA	*Feed Table Elevator Trip Return Lever	RF-308B	8	OGECK	Pump Valve Cage
RF-243P	Not Shown	OFUKR	Feed Table Elevator Trip Return Lever Pin	RF-308C	8	OGEDU	Pump Valve Cap
RF-243SS	Not Shown	OFULM	Feed Table Elevator Trip Return Lever Set Screw	RF-308E	8	OGEFT	Pump Valve Spring
RF-245A	7	OFUMS	Feed Table Elevator Trip Bracket	RF-310A	8	OGEGL	Pump Valve Flanged Washer
RF-245P	Not Shown	OFUNK	Feed Table Elevator Trip Bracket Pin	RF-310S	8	OGEHD	Pump Valve Flanged Washer Screw
RF-246	7	OFUPE	Feed Table Elevator Trip	RF-310SW	8	OGEJE	Pump Valve Screw Washer
RF-246P	Not Shown	OFURK	Feed Table Elevator Trip Pin	RF-311A	8	OGEKA	*Pump Crank Shaft Bearing Top
RF-246W	Not Shown	OFUSL	Feed Table Elevator Trip Pin Washer	RF-311S	8	OGELB	Pump Crank Shaft Bearing Top Screw
RF-248E	7	OFUTE	Delivery Table Side Jogger Plate Spring	RF-312	8	OGEMS	*Pump Crank Shaft Bearing Bottom
RF-249A	7	OFUVR	Delivery Table Side Jogger Cam	RF-325	8	OGENF	Pump Piston Rod
RF-249SS	1	OFUWA	Delivery Table Side Jogger Cam Set Screw	RF-325N	8	OGEPY	Pump Piston Rod Lock Nut
RF-250	1	OFUXY	Delivery Table Side Jogger	RF-329	8	OGERF	Pump Gasket
RF-250N	7	OFUYI	Delivery Table Side Jogger Nut	RF-330	8	OGESK	Pump Shaft
RF-250S	7	OFUZA	Delivery Table Side Jogger Screw	RF-330SS	8	OGETY	Pump Shaft Set Screw
RF-252AA	7	OFVAB	*Delivery Table Jogger Plate, Left	RF-330SSN	8	OGEVO	Pump Shaft Set Screw Nut
RF-252EH	7	OFVEN	Delivery Table Jogger Plate Spring Pin	RF-330T	3	OGEXP	Pump Shaft Oil Tube
RF-252S	7	OFVIO	Delivery Table Jogger Plate Screw	RF-330TC	3	OGEXT	Pump Shaft Oil Tube Clamp
RF-253A	7	OFVOS	Delivery Table Jogger Plate Gib	RF-333	8	OGELY	Pump Blast Hose
RF-253S	Not Shown	OFVUR	Delivery Table Jogger Plate Gib Screw	RF-333C	8	OGEZI	Pump Blast Hose Clamp
RF-255A	Not Shown	OFWAH	Delivery Table Side Jogger Cam Roll	RF-334	8	OGFAP	Pump Blast Hose Nipple
RF-256A	Not Shown	OFWEF	Delivery Table Side Jogger Cam Roll Pin	RF-335	8	OGFEW	Pump Vacuum Hose Nipple
RF-262	7	OFWIP	Delivery Table Front Jogger Rod Bracket	RF-336	8	OGFIV	Throw-Off Hose Nipple
RF-262S	Not Shown	OFWOM	Delivery Table Front Jogger Rod Bracket Screw	RF-337	2	OGFOY	Feed Air Line "Y" Fitting
RF-265A	7	OFWUK	Delivery Table Front Jogger	RF-339A	7	OGFUM	Feed Table Feeler Lift Lever Shaft
RF-265S	1	OFYAL	Delivery Table Front Jogger Adjusting Screw	RF-340	7	OGGAB	Feed Table Feeler Lift Lever
RF-265SS	1	OFYEG	Delivery Table Front Jogger Set Screw	RF-342	7	OGGEC	Feed Table Feeler Lift Lever Pin
RF-266	7	OFYIN	Delivery Table Front Jogger Rod	RF-343	7	OGGID	Feed Table Feeler Lift Shaft Collar
RF-266P	Not Shown	OFYOD	Delivery Table Front Jogger Rod Pin	RF-343SS	Not Shown	OGGOF	Feed Table Feeler Lift Lever Set Screw
RF-268	Not Shown	OFYUJ	Delivery Table Rear Jogger Ball	RF-344	7	OGGUH	Feed Table Feeler Counter Weight
RF-269	Not Shown	OFZAN	Delivery Table Rear Jogger Ball Spring	RF-345	7	OGHAL	Feed Table Feeler Lift Cam
RF-270	7	OFZES	Delivery Table Rear Jogger	RF-345SS	Not Shown	OGHEM	Feed Table Feeler Lift Cam Set Screw
				RF-347	7	OGHIN	*Feed Table Feeler Lift Cam Lever
				RF-347P	Not Shown	OGHOP	Feed Table Feeler Lift Cam Lever Pin
				RF-347SS	Not Shown	OGHUQ	Feed Table Feeler Lift Cam Lever Pin Screw
				RF-348	7	OGIBU	Feed Table Feeler Lift Cam Lever Roller

*Parts marked with an asterisk indicate special fitting and will be shipped with their mating part or parts
IMPORTANT- Be sure to mention size of press for which parts are being ordered

COMPONENT PARTS LIST—Continued





PLATE No 10

Part Number	Part Shown on Plate No.	Code	Name and Description
RF-350A	2	OGICO	Feed Cam Shaft Brace Connection
RF-350SS	Not Shown	OGIDE	Feed Cam Shaft Brace Connection Set Screw
RF-351A	2	OGIFA	Feed Cam Shaft Brace
RF-351S	2	OGIGS	Feed Cam Shaft Brace Screw
RF-353	8	OGIHK	Delivery Vacuum Pipe Connection Support
RF-360	7	OGIKU	Feed Table Worm Gear
RF-361	Not Shown	OGILF	Feed Table Fixed Release Ratchet
RF-362	Not Shown	OGIME	Feed Table Worm Gear Sleeve
RF-363A	7	OGING	Feed Table Sliding Release Ratchet
RF-364	Not Shown	OGIPS	Feed Table Sliding Release Ratchet Key
RF-365	Not Shown	OGIRB	Feed Table Sliding Release Ratchet Spring
RF-366	2	OGISM	Feed Table Sliding Release Ratchet Spring Collar
RF-366S	Not Shown	OGITA	Feed Table Sliding Release Ratchet Spring Set Screw
RF-367	8	OGIVU	*Feed Air Line Pipe Street Ell
RF-369	8	OGIWA	*Feed Air Line Pipe Tee
RF-370	9	OGIXL	*Feed Bar Clamp Tube
RF-372	9	OGIYA	*Feed Bar Sliding Tube
RF-375	9	OGIZO	*Feed Bar Sucker Tip Holder Clamp Screw
RF-376	9	OGJAW	Feed Bar Cross Head

Part Number	Part Shown on Plate No.	Code	Name and Description
RF-378	9	OGJEX	Feed Bar Rubber Sucker Tip Head
RF-381	9	OGJIY	Feed Bar Metal Sucker Tip (Long)
RF-382	9	OGJOZ	Feed Bar Metal Sucker Tip (Short)
RF-383	9	OGJUR	Feed Bar Rubber Sucker Tip Holder (Long)
RF-384	9	OGKAS	Feed Bar Rubber Sucker Tip Holder (Short)
RF-386	9	OGKET	Feed Bar Cross Head Plug
RF-389	9	OGKIV	Feed Bar Small Rubber Tip
RF-390	9	OGKOP	Feed Bar Dummy Sucker
RF-391	9	OGKUQ	Rubber Sucker Tip Emery Face (Small)
RF-392	9	OGLAN	Rubber Sucker Tip Emery Face (Large)
RF-396	9	OGLEM	Delivery Bar Sucker Tip Head
RF-399	9	OGLIL	Feed Table Setting Gauge
RF-407A	9	OGLOK	*Register Gauge Finger (4 1/8" long)
RF-407E	9	OGLUJ	Register Gauge Finger Spring
RF-407N	9	OGMAH	Register Gauge Finger Spring Nut
RF-407S	Not Shown	OGMEG	Register Gauge Finger Spring Stud
RF-407 1/2 A	9	OGMIF	*Register Gauge Finger (5 3/8" long)
RF-408A	9	OGMOD	*Register Gauge Finger (2 1/4" long)
RF-408 1/2 A	9	OGMUC	*Register Gauge Finger (4" long)
RF-409A	9	OGNAB	*Register Gauge Finger (3 1/8" long)
RF-410	6	OGNEW	*Register Operating Spool
RF-410N	6	OGNIV	Register Operating Spool Adjusting Nut

*Parts marked with an asterisk indicate special fitting and will be shipped with their mating part or parts.
IMPORTANT: Be sure to mention size of press for which parts are being ordered.



FEED & DELIVERY
BAR PARTS
CHANDLER & PRICE
CLEVELAND OHIO
SEPT. 9, 1937 A. Black
12 x 18

CRAFTSMAN Automatic Unit

CRAFTSMAN PRESSES

Rice Style Hand Fed and Automatic

R10 x 15 Unit		R12 x 18 Unit	
No.	Year	No.	Year
RC101	1932	RD101	1933
RC150	1933	RD113	1934
RC187	1934	RD163	1935
RC250	1935	RD300	1936
RC350	1936	RD537	1937
RC482	1937	RD904	1938
RC679	1938	RD1146	1939
RC769	1939	RD1312	1940
RC827	1940	RD1429	1941
RC879	1941	RD1572	1942
RC951	1942	RD1630	1943
RC1000	1943	RD1637	1944
RC1004	1946	RD1649	1946
RC1144	1947	RD1900	1947
RC1249	1948	RD2250	1948
RC1413	1949	RD2664	1949
RC1537	1950	RD2794	1950
RC1589	1951	RD2935	1951
RC1650	1952	RD3043	1952
RC1679	1953	RD3092	1953
RC1709	1954	RD3123	1954
RC1720	1955	RD3144	1955
RC1724	1956	RD3149	1956
RC1727	1957	RD3150	1957
RC1736	1958	RD3153	1958
RC1742	1959	RD3154	1959
RC1750	1960	RD3160	1960
RC1751	1961	RD3163	1961
RC1755	1962	RD3165	1962
DISCONTINUED		DISCONTINUED	

Craftsman Hand Fed

XC10 x 15	
No.	Year
XC100	1925
XC101	1926
XC102	1927
XC117	1931
XC145	1932
XC163	1933
XC167	1934
XC182	1935
XC202	1936
XC229	1937
XC236	1941
DISCONTINUED	

12 x 18 Craftsman

No.	Year
X100	1921
X130	1922
X900	1923
X1650	1924
X2101	1925
X2401	1926
X2720	1927
X3000	1928
X3199	1929
X3548	1930
X3725	1931
X3779	1932
X3788	1934
X3794	1935
X3808	1936
X3816	1938
X3846	1941
DISCONTINUED	

SD12 x 18 Unit

No.	Year
SD101	1940
SD110	1941
SD120	1942
SD126	1945
DISCONTINUED	

Cylinder Presses

No. 1 Cyl. (11 x 15)

No.	Year
CY101	1928
CY105	1929
CY110	1931
CY140	1932
CY201	1932
CY203	1933
CY301	1934
CY305	1935
CY318	1936
CY333	1937
CY343	1938
CY362	1939
CY380	1940
CY384	1941
CY388	1942
DISCONTINUED	

No. 2 Cyl. (12 x 18)

No.	Year
CY2 101	1939
CY2 121	1940
CY2 226	1941
CY2 299	1942
CY2 300	1943
CY2 313	1944
CY2 316	1949
CY2 332	1950
CY2 338	1951
CY2 401	1952
CY2 418	1953
CY2 423	1954
CY2 425	1956
CY2428	1957
DISCONTINUED	

Side Delivery Hand Fed and Automatic

10 x 15

No.	Year
SDC101	1954
SDC115	1955
SDC177	1956
SDC220	1957
SDC245	1958
SDC266	1959
SDC275	1960
SDC278	1961
SDC287	1962
SDC295	1963
SDC501	1964
DISCONTINUED	

12 x 18

No.	Year
SDD101	1954
SDD113	1955
SDD145	1956
SDD170	1957
SDD185	1958
SDD196	1959
SDD200	1960
SDD211	1961
SDD215	1962
SDD220	1963
SDD501	1964
DISCONTINUED	